

		Canon DSLR Cameras					
Lensbaby Lens	Rebel Series	1D/ 1DMKiiN/ 1Dx/ 1DxMKii 5D/ 5DMKii/ 5DMKiii/ 5D MKiv / 5DS/ 5DSr		10D	50D	100D	
	KISS Series	6D	7D/ 7DMKii	20D	60D	300D	500D
				20Da	60Da	350D	550D
				30D	70D	400D	700D
				40D	80D	450D	1000D
Velvet 56 SE	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Velvet 56	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Circular Fisheye	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Trio 28	N/A	N/A	N/A	N/A	N/A	N/A	
Twist 60	Not Recommended	Canon EF - AP/ M	Not Recommended	Not Recommended	Not Recommended	Not Recommended	
Composer Pro II with Sweet 35 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro II with Sweet 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro II with Edge 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro II with Edge 80 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Spark	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
<b>Discontinued</b>							
Composer Pro with Sweet 35 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro with Sweet 50 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro with Edge 80 Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer Pro with Double Glass Optic	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Muse	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Scout	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Control Freak	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	Canon EF - AP/ M	
Composer with Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A	
Tilt Transformer	N/A	N/A	N/A	N/A	N/A	N/A	

AP/ M = Camera will work in Aperture Priority Mode or Manual Mode and in-camera light meter will work

M = Camera will only work in Manual Mode and in-camera light meter will not work.